



Installing the MantisSport 987 Lower Stress Bar

Step #1

Remove the rear most tension plate studs. Hammer them up out of the suspension casting.

Step #2

Put 1 washer on each side of casting.

Step #3

Slide stress bar into place.

Step #4

Install 3/8" bolt with a washer on top of stress bar end.

Step #5

Washer and nut installed from underneath.

Step #6

Torque nut to 30 ft/lbs.

Step #7

Adjust and tighten the jam nuts on both sides of the stress bar.



Please note, photo is taken with rear swaybar removed. Temporary removal of rear swaybar may help facilitate installation.

Preparation + Passion = Performance

1029 Speers Road | Unit 6 | Oakville | Ontario | L6L 2X5 | 905-844-6219 | www.mantissport.ca