

MantisSPORT

Installation instructions for MantisSport Window Net Bar

The window net bar is spring loaded. This is to facilitate dropping of the window net. The heim end acts as a pivot and locator. This makes the job of putting up and down the window net that much easier.

Step.1 You will need a 3/8 bolt & nut to fit the heim end. This is not supplied as the main bar location will determine the length of the bolt.

Step 2. The heim end of the assembly is mounted by the bolt welded to the main roll bar.

Step 3. The steel sleeve is welded to the front roll bar, you must fit the sleeve to the roll bar and adjust the length so when the window net bar is collapsed the aluminum rod should be clear of the forward sleeve.

Step 4. Now you are ready to fit the window net and adjust the collar so the window net does not fall off the rod.



